

Care instructions for mineral casting with non-slip surface

HOESCH products set standards in quality, comfort and design.

Cleaning and caring for products with an anti-slip surface is simple and easy. Rinse with water after every bath and wipe with a damp, mild cloth.

For occasional basic cleaning, apply a few squirts of cleaning agent, e.g. Hoesch Cleaner (Art. No. 699900), to the surface and rub with a soft, dry cloth.

Remove heavier soiling with warm water and a mild liquid detergent or soapy water. Wipe away limescale deposits with distilled vinegar and water (avoid taps!).

Do not use any abrasive or scratching agents on the non-slip surface:

- Abrasive or scratching cleaning textiles and bath sponges
- Cleaners with slightly liquid acids such as hydrochloric or acetic acid (excluding spirit vinegar)
- Scouring milk
- Cleaning powder
- Cleaners containing chlorine bleach
- Special polishing cream for mineral casting
- Any hair colouring agent

⚠ Attention! Please do not sand the anti-slip surface, otherwise the anti-slip effect may be lost.

